

**Made available by using the most
modern techniques**


SLV 10 B

SLV 22 B

Operating Instructions

Instructions for the fitter

Fitting the oil burner



Picture 1: Drill stencil for securing flange

The sliding flange supplied with your equipment is used to fit the oil burner to the boiler and is secured to the boilerplate by using the four screws. The clamp sliding flange ensures that the flame tube is inserted sufficiently far into the body of the boiler to conform with the requirements of the boiler in question.

The elongated holes in the sliding flange are suitable for a pitch diameter of 150-180 mm. When fitting please ensure that the sliding flange is inclined at 3° in order to prevent oil running into the burner whilst the preheater is warming up. Please observe the "TOP" ("OBEN") marking! Tighten the upper screws firmly. Only use slight pressure to tighten the lower screws in order to permit the sliding flange to be retracted. After the sliding flange has been fitted to the boiler the flame tube is inserted and the sliding flange clamped by slightly lifting the burner. (6 mm Allen key).

Insertion depths

Certain types of boiler bodies prescribe specific insertion depths for the flame tube:

–Threepass boiler with recirculation combustion chamber:

Insert the burner deep enough to ensure that the front edge of the line burner projects into the combustion chamber (combustion chamber inset) by a few millimetres.

–Hot reversible combustion chamber:

Only insert far enough to ensure that the front edge of the line burner is flush with the door insulation.

–**Please note:** When working with older boilers which are fitted with large bodies it may be necessary to use a recirculation route. This will prevent the flame and mixing device becoming subject to undercooling.

Electrical Connection

Use a plug-type connector as prescribed by DIN EN 226. The socket section is fitted to the burner.


Please observe local electricity regulations. Please refer to the circuit diagram!

— **Please remove the burner plug before commencing work on the burner's electric system.**—

Oil Connection


Oil pipes are supplied and are to be fitted to the oil pump. They are secured by using the clamp strap - see Pos. 14 (front sheet) -. The isolating and filter armatures must be arranged in such a way that they do not interfere with the laying of the hoses, i.e. the hoses should not be bent.

Service Positions



Picture 2

The burner mounting plate can be removed from the housing once the four fast locks have been loosened - Pos. 3 (cover page) –and hung to the side. All functional parts are accessible and can be serviced with a minimum of effort.



Picture 3

The mounting plate can be hung horizontally whilst the burner stem is being serviced. This position is also selected when replacing the spray nozzle. Oil is not able to escape from the nozzle stem and air cannot infiltrate the system.

In accordance with DIN EN 267 Examination Regulations these burners conform to §7 Para. 2 of 1. BImSchV. dated 14. March 1997.

SLV B – Burner Features

As the most modern techniques have been applied the SLV – B oil burners may be fitted to all heating boilers.

The following features ensure universal use of the burners:

1. Variable insertion depth of mixer device into the body of the boiler. This means that various degrees of boiler door insulation can be compensated without having to invest in expensive flame tube extensions. The flame tube can be inserted in such a way on reversible flame boilers that the flame root is not positioned at the reversing point.
2. An adjustable air intake nozzle allows variation of the blower characteristics (see Picture 4). Advantage: The oil burner operates in the optimum steep area of the blower.
3. Secondary air adjustment (see Picture 5). By moving the retarding disk in the mixer device the mixing pressure can be adjusted.

Exhaust gas temperature

The exhaust gas temperature should be within the range of 160°C - 210°C. If temperatures fall below 160°C there is, under certain circumstances, the danger of condensate causing soot to build up. Please therefore ensure that the chimney fulfils the requirements.

Matching the burner, boiler and chimney.

Continuous pressure within the body of the boiler is necessary in order to ensure troublefree combustion. The ventilation capacity of the burner depends upon a certain amount of counterpressure. Transient pressure can cause superfluous air or respectively inadequate air. **In order to maintain continuous pressure within the body of the boiler it is necessary to install an air limiter or respectively a secondary air system.** Attention must also be paid to the appropriate dimensioning of the chimney cross section. Your chimney sweep and heating installer can give expert advice with regard to the dimensioning of the chimney and the secondary air system.


Exhaust gas thermometer

We recommend the installation of an exhaust gas thermometer for continuous control of the exhaust temperature. This thermometer is available at all specialist stores. The check bore in the exhaust pipe used by the chimney sweep is an ideal position for measuring the temperature. Should the exhaust gas temperature rise by more than 30°C this is the sign for a build up of coating in the boiler which in turn will lead to uneconomical operation of the heating system. The burner adjustment should be checked and, if necessary, the boiler cleaned. During the comparative reading please ensure that the burner operating periods were roughly the same as those before the reading was taken.


Running time meter

In order to be in a position to keep a check on oil consumption we recommend fitting the SLV – B burner with a running time meter. When comparing oil consumption it should not be forgotten that the outside temperature during certain months or respectively during certain years would have an effect on the consumption results.


Reference Input, Dimensions, Nozzle Recommendations SLV 10 B




Scale angle nozzle stem



Scale of the air-intake nozzle



Reference input mixer device



Burner Capacity	Oil Flow Rate	Nozzle Type: "Solid (S)"	Pump pressure	Position air damper	Air intake nozzle	Blower pressure	Nozzle stem
[kW]	kg/h	[gph] Angle	[bar]	Scale	Scale	[hPa]	[mm]
16	1,35	0,40 60°	10,0	1,0	0,0	2,0	6
18	1,57	0,45 60°	10,0	1,0	0,0	2,0	10
20	1,69	0,50 60°	10,0	1,5	0,0	2,0	10
22	1,85	0,50 60°	12,0	1,5	0,0	2,0	11
24	2,02	0,55 60°	11,0	2,0	0,0	2,2	12
26	2,19	0,55 60°	12,0	1,5	0,5	2,2	12
28	2,36	0,60 60°	10,0	2,0	0,5	2,2	13
30	2,53	0,60 60°	11,5	2,0	1,0	2,5	13
32	2,71	0,60 60°	13,0	2,0	1,0	2,5	14
34	2,86	0,65 60°	12,0	2,5	1,0	2,5	15
36	3,03	0,75 60°	10,0	2,0	1,5	2,5	16
38	3,20	0,75 60°	12,0	2,5	1,5	2,5	18
40	3,42	0,85 60°	10,0	2,8	1,5	2,5	19

These pre-adjustments were made using Danfoss nozzles at an X-measurement of 4 mm.

X-Measurement

Nozzle spray angle	45°	60°	80°
X-measurement SLV 10 B	5-6	3-4	2-3

Capacities other than those shown here are achieved by changing the pump pressure.

The burner should preferably be operated at a pump pressure of 10 - 15 bar.

This reference input should be regarded as synthetic data and is intended purely for pre-adjustment purposes.


The burner must be matched to the boiler before operation.

In some cases it may be necessary to use nozzles with different spray angles.


A 45° nozzle is often more suitable for hot reversible combustion chambers, whilst an 80° nozzle is better suited to short combustion chambers.

Reference Input, Dimensions, Nozzle Recommendations SLV 22 B


Mixer device




Scale angle nozzle stem



Scale of the air-intake nozzle



Reference input mixer device



Burner Capacity	Oil Flow Rate	Nozzle Type: "Solid (S)"	Pump pressure	Position air damper	Air intake nozzle	Blower pressure	Nozzle stem
[kW]	kg/h	[gph] Angle	[bar]	Scale	Scale	[hPa]	[mm]
35	2,95	0,75 60°	11	0,5	0	1,4	0
40	3,40	0,85 60°	11	1,0	0	2,6	3
45	3,80	1,00 60°	11	1,0	0	3,0	5
50	4,20	1,10 60°	11	2,0	0	3,2	7
55	4,70	1,25 60°	10	2,0	0	3,1	9
60	5,10	1,35 60°	12	2,0	1	3,4	11
65	5,40	1,50 60°	11	2,0	1	3,2	13
70	5,90	1,50 60°	12	2,0	1	3,7	14
75	6,40	1,75 60°	11	3,0	1	3,8	15

These pre-adjustments were made using Danfoss nozzles at an X-measurement of 5 mm.

X-Measurement

Nozzle spray angle	45°	60°	80°
X-Measurement SLV 22 B	6-7	4-5	3-4

Capacities other than those shown here are achieved by changing the pump pressure.

The burner should preferably be operated at a pump pressure of 10 - 15 bar.

This reference input should be regarded as synthetic data and is intended purely for pre-adjustment purposes.


The burner must be matched to the boiler before operation.

In some cases it may be necessary to use nozzles with different spray angles.

A 45° nozzle is often more suitable for hot reversible combustion chambers, whilst an 80° nozzle is better suited to short combustion chambers.

Burner Pre-Adjustment


After the required nozzle has been fitted (see list on page 5) and the ignition electrodes adjusted (see page 4), the burner is pre-adjusted by an expert fitter as follows:



Picture 4

1. Pre-adjustment of the air intake nozzle


After the locking screw (Picture 5) has been loosened, use the service key and the pinion (Picture 4) to pre-adjust the burner compression without flame in the housing in accordance with the reference values (see tables on page 4 or respectively 5). Re-tighten the locking screw after adjustment has been completed.



Picture 5

2. Pre-adjustment of the nozzle stem


Using the service key adjust the regulating screw to pre-adjust the nozzle stem without flame in accordance with the reference values (see list page 5). The numerical values can be taken from the scale angle.



Picture 6

3. Ventilator regulating screw

Pre-adjust the ventilator regulating screw at the side on the upper left side of the burner housing in accordance with the reference values (see list page 5). Use milled nut to counter.



Picture 7

4. Pressure gauging nipple

The blower pressure can be measured in order to check the correct adjustment.


Optimum values are between 1,5 and 4 mbar depending upon burner capacity, boiler resistance or air reaction.

Initial Operation of the Burner

Once the pump pressure gauge has been fitted the burner may be put into operation. The pump pressure should be adjusted as required. The **CO₂ content** of the exhaust gas should be checked immediately and corrected, if necessary, by using the nozzle stem or the ventilator (**12.0-13.0%**).

An expert fitter must carry out any necessary post adjustment to the burner as follows:


Minor correction of the CO₂-(O₂-) content should preferably be carried out by slight adjustment to the nozzle stem setting screw.



Picture 8

By turning the setting screw on the nozzle stem to **the right** (page 6, Picture 4) in the direction of the **greater scale values the amount of air is increased and the CO₂ content of the exhaust gas reduced.**

By turning to the left the amount of air is reduced and the CO₂ content of the exhaust gas increased.




Picture 9

By turning the ventilator setting screw **to the right** the mixing pressure is **reduced**, as is the amount of air. This results in an **increased CO₂ value.**

Turning to the left increases the mixing pressure and the amount of air and the **CO₂ value is reduced.**

Please tighten the counternut once the adjustment has been completed.



Picture 10

If a build up of soot is observed when the ventilator and the mixer device are open wide or when the burner has to overcome major starting resistance (start-up whilst ventilator is pulsating) it may be necessary to adjust the air intake nozzle to a greater scale value.


This can also mean that the ventilator and the nozzle stem may have to be re-adjusted.

The combination of these adjustments, - reducing (or respectively increasing) the CO₂ by means of the ventilator and perhaps the intake nozzle, followed by increasing (or respectively reducing) to 12 – 13% by adjusting the nozzle stem, - allows optimum adjustment to a variety of system requirements.


The flame can be adjusted to suit a variety of boiler bodies. The flame will be long if it has been produced using a small amount of mixing pressure and short and compact if produced using a high amount of mixing pressure.

Circuit Diagram

For SLV - B with Satronic burner safety control



For SLV - B with Landis & Gyr burner safety control




Troubleshooting

Problem:	possible cause:	solution:
burner motor will not start	<ul style="list-style-type: none"> - no supply voltage - safety thermostat locked - nozzle stem oil pre-heater faulty - control device faulty - motor faulty - oil pump tight 	<ul style="list-style-type: none"> - replace fuse - unlock - replace - replace - replace - clean or replace
burner starts up but switches to "fault" after expiry of safety period	<ul style="list-style-type: none"> - no ignition - burner not being supplied with oil: <ul style="list-style-type: none"> - oil tank empty - dirty filters - oil supply line leaking - foot valve leaking - oil supply line valves closed - oil conveyor aggregate faulty - burner oil pump faulty - pump coupler faulty - flame detector faulty or dirty - outside light effecting flame detector - nozzle dirty or faulty - solenoid valve not opening 	<ul style="list-style-type: none"> - ignition electrodes and adjustment, - check ignition transformer and cable - fill up oil tank - replace - seal - clean - open - replace - replace - replace - replace or clean - locate light source - replace - replace coil or complete solenoid valve
Motor starts up burner but after c. 12 seconds burner switches to "fault".	<ul style="list-style-type: none"> - solenoid valve not closing 	<ul style="list-style-type: none"> - replace valve tappet or complete solenoid valve
Flame goes out during operation	<ul style="list-style-type: none"> - no oil left - nozzle filters clogged - oil filter or oil supply line dirty - trapped air 	<ul style="list-style-type: none"> - fill up with oil - replace nozzle - replace filter, clean supply line - check suction pipe and armatures

Please note: Additional information on the Satronic System can be found on the last page.

Technical Data, Capacity Diagram





Type: SLV 10 B

Nominal capacity range: 17 - 40 kW
 Oil flow rate: 1,4 - 3,4 kg/h
 Nominal voltage: 230 V / 50 Hz
 Nominal circuit: 240 W
 Fuel: Heating fuel oil EL

Type: SLV 22 B

Nominal capacity range: 33 - 78 kW
 Oil flow rate: 2,8 - 6,6 kg/h
 Nominal voltage: 230 V / 50 Hz
 Nominal circuit: 290 W
 Fuel: Heating fuel oil EL

Pump Connections – Piping Dimensions




Legend:

S	= Suction pipe	R	= Return pipe
P	= Pump pressure gauge	V	= Vacuum gauge
DV	= Pressure adjustment	DL	= Nozzle pipe
MV	= Solenoid valve		


Suction pipe designation for heating fuel oil EL

2-pipe system with elevated tank



H [m]	4,0	3,5	3,0	2,5	2,0	1,5	1,0	0,5
Ø 6 [mm]	33	31	29	27	25	23	21	19
Ø 8 [mm]	100	98	91	85	79	72	66	60
Ø 10 [mm]	100	100	100	100	100	100	100	100

2-pipe system with lowered tank



H [m]	-0,0	-0,5	-1,0	-1,5	-2,0	-2,5	-3,0	-3,5	-4,0
Ø 6 [mm]	17	15	13	11	9	7	5	3	1
Ø 8 [mm]	53	47	41	34	28	22	15	9	3
Ø 10 [mm]	100	100	99	84	68	53	37	22	6


Fuel:

Only mineral heating fuel oil in accordance with DIN 51603 Part 1 with a maximum viscosity of 6 mm²/s (cSt) at 20 °C may be used.

The flow speed of the heating fuel oil should be between 0.2 and 0.5 m/s.

Piping Dimensions

Single pipe system with elevated tank



Oil flow rate up to 2.5 kg/h

H [m]	4.0	3.5	3.0	2.5	2.0	1.5	1.0	0.5
Ø 4 [mm]	51	45	38	32	26	19	13	6
Ø 5 [mm]	100	100	94	78	62	47	31	16
Ø 6 [mm]	100	100	100	100	100	97	65	32


Oil flow rate up to 5.0 kg/h

H [m]	4.0	3.5	3.0	2.5	2.0	1.5	1.0	0.5
Ø 4 [mm]	26	22	19	16	13	10	6	3
Ø 5 [mm]	62	55	47	39	31	23	16	8
Ø 6 [mm]	100	100	97	81	65	49	32	16

Oil flow rate up to 10.0 kg/h

H [m]	4.0	3.5	3.0	2.5	2.0	1.5	1.0	0.5
Ø 5 [mm]	31	27	23	20	16	12	8	4
Ø 6 [mm]	65	57	49	40	32	24	16	8
Ø 8 [mm]	100	100	100	100	100	77	51	26

Single pipe system with lowered tank



Oil flow rate up to 2.5 kg/h

H [m]	-0.0	-0.5	-1.0	-1.5	-2.0	-2.5	-3.0	-3.5	-4.0
Ø 4 [mm]	52	46	40	33	27	21	15	9	2
Ø 5 [mm]	100	100	97	81	66	51	36	21	6
Ø 6 [mm]	100	100	100	100	100	100	75	44	12

Oil flow rate up to 5.0 kg/h

H [m]	-0.0	-0.5	-1.0	-1.5	-2.0	-2.5	-3.0	-3.5	-4.0
Ø 4 [mm]	26	23	20	17	14	10	7	4	1
Ø 5 [mm]	63	56	48	41	33	26	18	11	3
Ø 6 [mm]	100	100	100	84	69	53	37	22	6

Oil flow rate up to 10.0 kg/h

H [m]	-0.0	-0.5	-1.0	-1.5	-2.0	-2.5	-3.0	-3.5	-4.0
Ø 5 [mm]	32	28	24	20	17	13	9	5	1
Ø 6 [mm]	66	58	50	42	34	27	19	11	3
Ø 8 [mm]	100	100	100	100	100	84	59	35	10

Flash Code of the Satronic Information System *)

The Satronic DKO and DKW Burner Control Information System indicates the procedures in connection with the burner control unit and burner observation. It provides continuous information with regard to the programme phase currently governing the device. This communication is by means of a flash code. Special scanners such as PC, Laptop (Notebook), PalmPilot or SatroPen can be used to simplify communication.

1.1 Programming sequence display

The built-in microprocessor controls not only the programming sequence but the information system too. The individual phases of the programming sequence are displayed as Flash-Code.

The following messages can be distinguished:


Message	Flash-Code
waiting for control thermostat	.
pre-ignition	.
safety time ts	■ .
post ignition tn	
delay 2nd stage	■ .
running	_
low mains voltage	■ ■ _

Description
 | = short pulse
 ■ = long pulse
 . = short pause
 _ = long pause

1.2 Lock-out diagnoses

In case of a failure the LED is permanently illuminated. Every 10 seconds the illumination is interrupted by a flash code, which indicates the cause of the error. Therefore the following sequence is performed which is repeated as long as the unit is not reset.

Sequence:



Error diagnosis	Error message	Flash-Code	Possible fault
lock out	lock out	■ ■ ■ ■	within lock out safety time no flame establishment
stray light	stray light	■ ■ ■	stray light during monitored phase, detector may be faulty
limit thermostat time-out	limit thermostat time-out	■ ■	contact of limit thermostat does not close within 400 sec.

Flash-Code for manual lock out

manual/external lock out	■ ■ ■ ■ _ ■ ■ ■ ■ ■
--------------------------	---------------------

Initial Operation Protocol for Oil Burner

Customer: _____
 Heating Technician present: _____

Burner type: _____ Man. No.: _____
 Boiler manufactured by: _____ Type: _____
 Heating capacity: _____ kW Year built: _____

Measuring Report:	1 st reading		Measuring Report:	1 st reading	
Manufacturer of nozzle			Exhaust gas temperature		°C
Size / Spray angle		gph / °	Room temperature		°C
Pump pressure		bar	Pressure at retarding disk		hPa (mbar)
Flow		kg/h	Air at rear of boiler		hPa (mbar)
CO ₂		%	Pressure in body of boiler		hPa (mbar)
O ₂		%	Exhaust gas loss		%
CO		ppm	Position of nozzle stem		
NO _x		ppm	Position of air intake nozzle		
Soot					

Date: _____

Signature of customer

Signature of engineer

Handed over by:

Subject to technical alterations.